

# Schaefferstown Fire Co.

## Antique Tractor Pull Rules

1. Tractors must be registered and weighed to pull.
2. Tractors must be operated in a safe manner at all times.
3. Only one driver per tractor per class.
4. The driver must start the pull with a tight chain and at the starting signal from the flag man.
5. A hand throttle must control speed only. String, wires or foot feeds will not be allowed.
6. Drivers must remain on the seat and maintain full control of the tractor during pull.
7. Tractors losing weight or other objects while hooked to the sled will be disqualified.
8. Tractors must stay within the pull boundaries.
9. If a puller fails to pass the 50' mark, one restart will be allowed.
10. Tractors must stop at the red flag signal from the flagman.
11. All decisions of the Pulling Committee are final. Any arguments will result in automatic disqualification.
12. Any driver under 18 years old must have written consent from a parent or guardian with supervision present.

**ALL PARTICIPANTS PULL AT THEIR OWN RISK!  
PLEASE KEEP SAFETY IN MIND AND HAVE FUN!  
ENTRY FEE \$20.00 PER HOOK**

### Antique Class

Tractors must be model year 1965 or earlier to participate in the antique tractor pull. Tractors must be wheel driven by two wheels only.

# Schaefferstown Fire Co.

## Inspection

Tractors will be inspected during registration and weigh-in by the pull committee. Any tractors found to be unsafe or in violation of the rules will not be allowed to pull.

## Drawbar

The drawbar must be original or match factory specifications with a maximum height of 18 inches. The length of the drawbar must be a minimum of 24 inches from the center of the rear axle to hook point. The drawbar must be rigid with no more than 1 inch of movement in any direction. Use of flat-plate with 3-inch hole or twisted clevis only.

## Weights

May add weight to make class. Weight brackets must be bolted on. Weight must be securely fastened.

## Tires and Rims

Rim diameters may not be larger than factory specifications. Steel wheels cut down and converted to rubber shall have rims no longer than factory specifications. The use of dual wheels will not be allowed. Tires two sizes over standard size will be permitted. Steel wheels will not be permitted. Wheel rims and lugs must be to factory specifications. No cut tires.

## R.P.M.

R.P.M. maximum of 10% over the factory subject to check at any time.

## OPEN CLASS

Tractors not conforming to above specs may pull in open class with a max drawbar height of 20 inches and a minimum of 18 inches from the center of the axle. A maximum tire size of 18.4 inch x 38 inch will be allowed.